

5-11

Digital Multimeter Operating Instruction



VOLTH 5-11

Digital Multimeter
Operating Instruction

*The New Color
of Instruments.*

WWW.VOLTH.NET INFO@VOLTH.NET

Instruction manual

I. General introduction

Welcome to use this product!

This product VOLTH S-11 multipurpose automatic measuring range instrument, 6000 counts, may measure the AC/ DC voltage, the AC/ DC electric current, the resistance, the frequency, the electric capacity, the test for pass or break, the diode parameter and so on. The measuring appliance is loaded with guards against the surge electric discharge, protect the appliance to be more effective. This measuring appliance structure is exquisite, the operation is easy, it is your ideal test service tool!

II. Safety Rules and Notes

The design of this measuring appliance conforms to the safety standard of IEC61010-1. Please read this handbook carefully before use.

2.1 notes on security mark

-  Warning, be careful!
-  Danger of being hit by high-pressured electric!
-  Dual insulation protection.
-  Earth.
-  Low Battery.

2.2 when measure, do not surpass the greatest stipulated input value.

2.2 do not surpass 10V voltage to the input end, except the voltage grade

2.4 In the process of measuring, do not turn switch to change the measuring range at random, in case to destroy the measuring appliance.

2.5 The measuring appliance can display the mark while the voltage is bigger than DC60V and AC30V, remind the user that the measured voltage has surpassed the safety voltage, please operate carefully.

2.6 measuring appliances should avoid the straight sunlight, the high temperature, and moisture.

2.7 after use, must release the power switch to turn off the power

2.8 if it doesn't use for a long time, should take out the battery, in case the battery leaks todamage the parts.

III. Features

3.1 General Features

3.1.1 take the CMOS big scale integrated circuit as the core, in AC / DC voltage, the AC/DC electric current, the resistance, the frequency and the electric capacity measure it can automatically transform the measuring range, making it more convenient.

3.1.2 greatest display: 6000 Counts (3 6/7)

3.1.3 has the function of back light, data hold, the maximum/ minimum value hold measure.

3.1.4 automatic cathode display: Displays " - "

3.1.5 batteries insufficient display: Displays "  "

3.1.6 Auto power OFF

After turning on the instrument and without turning the function switch or pressing any button, the instrument will automatically enter into sleep mode after

10 minutes, to save battery power. when it is in the sleep mode you can press the SELECT key to wake up the instrument. If you don't need the automatic sleep mode, you should hold down the SELECT key to turn on the instrument, and then the symbol "ⓘ" will not be display on the LCD.

3.1.7 working condition : 0°C~40°C, 75%RH (max)

3.1.8 storage environment : -10°C~60°C, 80%RH (max)

3.1.9 battery : 9V(6F22 or equivalent)

3.1.10 external dimensions : 180 (length) 90 (width) 40 (height) mm.

3.1.11 weight : approximately 348g (contain battery)

3.2 technical index

3.2.1 DCV

Funtion	Range	Resolution	Accuracy
DC Voltage (V)	6.000V	0.001V	± (0.5% of reading ± 3 Digit)
	60.00V	0.01V	
	600.0V	0.1V	
	1000V	1V	
DC Voltage (mV)	60.00mV	0.01mV	
	600.0mV	0.1mV	

Input resistance : 10MΩ. Overload protection : DC/AC peak val

3.2.2 ACV

Funtion	Range	Resolution	Accuracy
AC Voltage (V)	6.000V	0.001V	± (1% of reading ± 3 Digit)
	60.00V	0.01V	
	600.0V	0.1V	
	750V	1V	
AC Voltage (mV)	60.00mV	0.01mV	
	600.0mV	0.1mV	

Input resistance : 10MΩ. Frequency : 10Hz~1kHz (Warning : Frequency for square wave accuracy is specified from 10Hz to 400Hz). display : TRUE RMS (sinusoidal waveform RMS calibration). Overload protection : 250V at mV range, DC1000V or peak value AC1000V at V range.

3.2.3 DCA

Funtion	Range	Resolution	Accuracy
DC Current (A)	6.00A	0.001A	± (2% of reading ± 5 Digit)
	20.00A	0.01A	
DC Current (mA)	60.0mA	0.01mA	
	600.0mA	0.1mA	
DC Current (μA)	600.0μA	0.1μA	
	6000μA	1μA	

Overload protection : μA/mA : F1 A/250V with fuse, 10A : F10 A/250V with fuse.

 greatest input electric current : 10A (less than 10 seconds). voltage drop measure : full measure range is 600mV.

3.2.4 ACA

Funtion	Range	Resolution	Accuracy
AC Current (A)	6.00A	0.001A	± (2.5% of reading ± 5 Digit)
	20.00A	0.01A	
AC Current (mA)	60.0mA	0.01mA	
	600.0mA	0.1mA	
AC Current (μA)	600.0μA	0.1μA	
	6000μA	1μA	

Overload protection : μA/mA:F1 A/250V with fuse, 10A F1 0A/250V fuse. Voltage drop measure : full measure range is 600mV(10A is 100mV). Frequency : 10Hz~1kHz (Warning : Frequency for square wave accuracy is specified from 10Hz to 400Hz). display : TRUE RMS(sinusoidal waveform RMS calibration).

 greatest input electric current : 10A (less than 10 seconds). voltage drop measure : full measure range is 600mV.

3.2.5 resistance Ω

Funtion	Range	Resolution	Accuracy
Resistance	600.00Ω	0.1Ω	± (1% of reading ± 2 Digit)
	6.000kΩ	0.001Ω	
	60.00kΩ	0.01kΩ	
	600.0kΩ	0.1kΩ	
	6.000MΩ	0.001MΩ	
	60.00MΩ	0.01MΩ	

Overload protection : 250V virtual value. Plough voltage approximately 0.5V.

3.2.6 CAP

Funtion	Range	Resolution	Accuracy
Capacitance	9.999nF	0.001nF	± (2.5% of reading ± 3 Digit)
	99.99nF	0.01nF	
	999.9nF	0.1nF	
	9.999μF	0.001μF	
	99.99μF	0.01μF	
	999.9μF	0.1μF	
	9.999μF	0.001mF	

Overload protection : 250V virtual value.

3.2.7 FREQ

Funtion	Range	Resolution	Accuracy
Frequency	99.99Hz	0.01Hz	± (0.1% of reading ± 1 Digit)
	999.9Hz	0.1Hz	
	9.999kHz	0.001kHz	
	99.99kHz	0.01kHz	
	999.9kHz	0.1kHz	
	60.00MHz	0.01MHz	

Overload protection : 250V/virtual value, input delicacy : 1V.

Caution : if the measured frequency is above 30V, please press "Hz/DUTY" key at AC electric voltage measuring range to get to the frequency function, then carry on measure.

3.2.8 occupancy and vacancy ratio

Measure range	Accuracy	Resolution
1% ~ 99%	$\pm(0.5\%+3d)$	0.1%

Overload protection : 250Vvirtual value.

3.2.9 temperature (general type)

Function	range	Resolution	Accuracy
TEMP	-20~1000°C	1°C	$\pm (0.5\% \text{ of reading})$
	-4~1832°F	1°F	$\pm 2 \text{ Digit}$

Overload protection 250V.

3.2.10 Diode positive voltage \blacktriangleright

Display of similar diode positive voltage. Measuring condition : positive DC electric current 2mA, reverse DC voltage approximate 3.2V.

3.2.11 Connection & disconnection measure

When the transited resistance is smaller than about 50Ω ,the buzzer beeps.
Measuring condition : plough voltage is about 0.5V.

IV. Application method

4.1.1 RANGE key,

RANGE key for the automatic / manual measuring range key, in the trigger movement way, before start the device it is at the automatic measuring range. It changes to manual measuring range when press it. At manual measuring range it goes upward one gear with one push, after it reaches the top gear, it goes downward to the lower-gear gradually with continuous press, and it takes turns. If press this key over 2 seconds, it changes back to the automatic measuring range condition.

4.1.2 DH/LIGHT key

The DH/LIGHT key is maintenance / the back light control key for the reading. A.DH reading maintenance in the trigger movement way, when touches the key lightly, display value is locked and maintained invariably, and shows " DH "on the monitor; When presses again, the fixed condition is relieved, enters into the usual measure condition. B.LIGHT: back light controls press LIGHT key more than 2 seconds to open the back light control signal, opens after the back light signal presses more than 2 seconds again switches off the back light control signal. After opening the back light, if don't press the LIGHT key for more than 2 seconds, it will shut off automatically after 10 seconds

4.1.3 SELECT key The SELECT key: function choice key, in the trigger movement way. may select the pattern: Chooses DC or AC under the DC/AC condition; Chooses under the temperature measure condition it needs . in the DC/AC Condition

choose, in temperature measure condition choose C° or F°. in the Diode/Beeper condition choose Diode or Beeper, in the Ohm/Cap/ Diode/ Beeper condition choose Ohm, Diode or Beeper.

4.1.4 Hz/DUTY key

Hz/DUTY is a choose key of frequency / duty ratio, worked as the way of triggering. Under the pattern of frequency survey, pressing the key can choose the pattern of frequency or duty ratio. Under the pattern of AC voltage or AC electric current, pressing the key can choose the survey pattern of voltage/frequency/duty ratio or electric current.

4.1.5 MAX/MIN value hold key

1) Pressing the MAX/MIN key namely enters the MAX pattern, which always maintains the maximum value of measurement.; And the second pressing of the key namely enters the MIN pattern, which always maintains the minimum value of measurement; Pressing again enters the MAX-MIN pattern ,duplicates above circulates. After entering the pattern of MAX/MIN will automatically enters the manual measuring range, The time of pressing the MAX/MIN key more than 2 minutes will lead to the quit of MAX/MIN measuring pattern.

4.2 DC/alternating voltage measure

turn the Range switch to V and this time the measuring appliance is set as the DC voltage measuring range of automatic shift gears. Insert the black pen into COM jack, and the red table pen into V/ Ω /Hz jack. For example, the measuring of DC voltage is to merge the table pen at the beginnings and ends of the measured electric circuit, which can directly read the number on the liquid crystal display monitor. If one wants to measure the alternating voltage, press SELECT key to the pattern of alternating voltage, and then merge the table pen with the measured electric circuit to read the showed number. If manually choose measuring scope is needed, press RANGE key to choose.

4.3 Measurement of alternating/DC electric current

turn the Range switch to the range of electric current, this time the measuring appliance is set as the direct current automatic shift gears in advance. Insert the black table pen into COM jack, and the red table pen into 10A or μ A/mA jack. If one wants to measure DC, one can concatenate the table pen with the measured electric circuit, which can directly read the number on the liquid crystal display monitor; If one wants to measure alternating current, press SELECT key to alternating current measuring range, then concatenate the table pen with the measured electric circuit to read the showed number. If one needs to choose measuring scope manually, press RANGE. If one does not know the measured electric current scope before survey, one should set the range key to the highest measuring range and adjust downward by the files. When the display monitor only displays OL, that is to say, the measured electric current has surpassed the measuring range and the switch of measuring range needs to move the high one grade. μ A/mA jack represents that the maximum input current is 600mA. The overload inputs can burn the internal installation fuse out and should be replaced immediately. 10A jack, without a fuse, the time of measuring should be less than 10 seconds to avoid the heating of lines, which would influence accuracy.

4.4 Resistances



Warnings! Before the survey of resistance, one must guarantee that the measured electric circuit or part does not have the voltage.

- 1) Adjust the revolving the Range switch to Ω position, and this time the measuring appliance will be set for the resistance measuring range.
- 2) Insert red table pen into the V/ Ω /Hz jacks, black table pen into " COM " jack.
- 3) Connect the pen with the beginnings and ends of the test circuit to read the resistance value.
- 4) If the manual choice measuring range scope is needed, press RANGE to choose. When the table pen is overloaded input, display monitor can display " OL ".

4.5 Measurement of forward voltage of diode

- (1) turn the Range switch to " $\rightarrow|+$ " position. press "SELECT" to $\rightarrow|+$ measuring range
- (2) insert the red pen to "V/ Ω /Hz" jack, insert the black pen to COM" jack. (red pen "+")
- (3) connect the test pen to the two ends of the measured to read positive voltage.
- (4) when the diode is reverse connected or the input end leads the way, the display monitor can display " OL ".
- (5) the diode does not have the simulation strip display.

4.6 Connection & disconnection measure

- (1) turn the Range switch to " $\bullet||$ " position, press "SELECT" key to $\bullet||$ measuring range.
- (2) insert red pen to "V/ Ω /Hz" jack, insert black pen to "COM" jack.
- (3) if the measured resistance is less than about 50 Ω , the buzzer will beep. This is the pass or break measure.



Caution :

- a. when the input end leads the way, it displays "OL".
- b. the measured circuit should be measured under the off-power condition, because any overload signal would make the buzzer beep, thus cause wrong measure.

4.7 capacitance measur



Warnings! When measure the electric capacity, must guarantee the measured capacitor has sent the electricity out, if the big electric capacity contains the oversized non- electric capacity ingredient, possibly affects the measuring accuracy.

- (1) turn the Range switch to " $\text{---}||\text{---}$ " position . General type press "SELECT" key to CAP measuring range.
- (2) insert the red pen to "V/ Ω /Hz" jack, insert black pen to "COM" jack.
- (3) connect the test pen to the two ends of the measured capacitor, could get the capacity value.
- (4) capacity position can not set the measuring range manually, no simulation strip display. when the capacity value is big, the measure may need about 10 seconds.

4.8 frequency/DUTY measure

- (1) turn the Range switch to Hz measuring range.
- (2) insert red pen to "V/ Ω /Hz/CAP"jack, insert black pen to "COM" jack.

(3) connect the test pen to the measured circuit, get the frequency value. press Hz/DUTY key, it displays "Hz", change it to "%" to get the ratio.



Caution :

- (1) Frequency grade can not set measuring range manually, no simulation strip display.
- (2) If the measured frequency is above 30V, please press "Hz/DUTY" key at "ACV" measuring range to frequency function for measure. By this method, it can bear 700V voltage, in case the voltage is too high to damage the meter . it can reduce the voltage to the best range IC is able to deal.

4.9 temperature measure Turn the

range switch to C°/F°, insert the k type black plug to "COM"jack, insert red one to "V/Ω/Hz"jack, the meter displays the temperature now .



Caution :

When the meter without inserted with temperature tool, it displayd environment temperature (normal temperature) .Attached K type WRNM-010,the temperature is 250C° (482 F°).

V. Maintenance



Warnings! before open the cover or the battery cover, cut off the power source and test pen and any input signal, in case electric shock.

5.1 when the meter displays "  ", must replace the battery. Open the battery cover, replace with the same type new battery to keep it work well.

5.2 keep the meter and test pen clean, dry and not damaged, could use the clean cloth or cleanser to clean the cover, do not use abrasive or solvent.

5.3 avoid damage, shake, shock, avoid high temperature and strong magnetic field.

5.4 should be corrected at least once per year

VI. Accessories

6.1 Test lead: 1 set

6.2 users manual: 1 piece

6.3 Temperature sensors: 1 set

6.4 cloth bag: 1piece

VOLTH